



APPLICABLE FOR USA, CANADA OR WHERE APPROVED TO THE USAGE

CAUTION: TO PREVENT ELECTRICAL SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.
ATTENTION: POUR ÉVITER LES CHOCS ÉLECTRIQUES, INTRODUIRE LA LAME LA PLUS LARGE DE LA FICHE DANS LA BORNE CORRESPONDANTE DE LA PRISE ET POUSSER JUSQU'AU FOND.

CAUTION: FOR CONTINUED PROTECTION AGAINST RISK OF FIRE, REPLACE ONLY WITH SAME TYPE FUSE AND RATING.
ATTENTION: UTILISER UN FUSIBLE DE RECHANGE DE MEME TYPE ET CALIBRE.

~~**WARNING: SHOCK HAZARD - DO NOT OPEN.**~~
~~**AVIS: RISQUE DE CHOC ELECTRIQUE - NE PAS OUVRIR.**~~

* **Explanation of Graphical Symbols**



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert you to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert you to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING! TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE

- Read Instructions;** All the safety and operating instructions should be read before the appliance is operated.
- Retain Instructions;** The safety and operating instructions should be retained for future reference.
- Heed Warnings;** All warnings on the appliance and in the operating instructions should be adhered to.
- Follow Instructions;** All operating and other instructions should be followed.
- Water and Moisture;** The appliance should not be used near water – for example, near a bath tub, washbowl, kitchen sink, laundry tub, in a wet basement or near a swimming pool etc.
- Attachments;** Do not use attachments not recommended by the appliance manufacturer as they may cause hazards.
- Accessories;** Do not place this appliance on an unstable cart, stand, tripod, bracket or table. The appliance may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket or table recommended by the manufacturer, or sold with the product. Any mounting of the appliance should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.
- Carts and Stands;** The appliance should be used only with a cart or stand that is recommended by the manufacturer.

PORTABLE CART WARNING

S3125A



- Wall or Ceiling Mounting;** The appliance should be mounted to a wall or ceiling only as recommended by the manufacturer.
- Ventilation;** The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug or similar surface that may block the ventilation openings; or placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.
- Heat;** The appliance should be situated away from sources such as radiators, stoves or other appliances that produce heat.
- Power Source;** The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.

13. **Power-Cord Protection;** Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles and the point where they exit from the appliance.
14. **Cleaning;** The appliance should be cleaned only as recommended by the manufacturer.
15. **Nonuse Period;** The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.
16. **Lightning;** For added protection during a lightning storm, or when it is left unattended and unused for a long periods of time, unplug it from the wall mains outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.
17. **Power Lines;** An outside antenna system should not be located in the vicinity of overhead power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.
18. **Overloading;** Do not overload wall mains outlets, extension cords or integral convenience receptacles as this can result in a risk of fire or electric shock.
19. **Object and Liquid Entry;** Care should be taken so that objects do not fall into and liquids not spilled into the inside of the appliance.
20. **Damage Requiring Service;** The appliance should be serviced by qualified service personnel when:
 - A. The power-supply cord or the plug has been damaged; or
 - B. Objects have fallen into or liquid has been spilled into the appliance; or
 - C. The appliance has been exposed to rain; or
 - D. The appliance does not appear to operate normally or exhibits a marked change in performance; or
 - E. The appliance has been dropped or the cabinet damaged.
21. **Servicing;** The user should not attempt to service the appliance beyond those means described in the operating instructions. All other servicing should be referred to qualified service personnel.
22. **Grounding or Polarization;** Precautions should be taken so that the grounding or polarization means of an appliance is not defeated.
23. **Replacement Parts;** When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.
24. **Safety Check;** Upon completion of any service or repairs to this appliance, ask the service technician to perform safety checks to determine that the product is in proper operating condition.
25. **Stacking;** Do not place any other equipment/unit above or beneath the subject unit.

26. **Antenna Grounding;** If an outside antenna or cable system is connected to the appliance, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up of static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to the antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection of grounding electrodes and requirements for the grounding electrode. (Refer to the diagram)

